

..omnicharge™

Omni Power Station 20C+

Need Power? Grab a Charger !

Step One:

Pick a charger

Select any available Omniccharge charger from the Power Station.

Step Two:


Charge up

Charge your laptop, tablet, phone, or practically any other devices.

Step Three:

Return when done

When you're finished, simply plug the charger back into any available slot.



Button Fuction

PRIMARY CONTROLS

-  - Quick press to power On
- Long press to power Off
-   - Left Button: On/Off DC Outlet
- Right Button: On/Off HUB

MENU CONTROLS

-  - Double press to enter the menu
- Quick press to select
-   - Left Button: Move Up
- Right Button: Move Down


Up to 8 charges
Smartphone


Up to 2 charges
15" Laptops


Up to 4 charges
Tablet


Up to 16 charges
Action Cam


Up to 10 charges
DSLR Camera


Up to 4 charges
Drone

For more information, please visit www.omnicharge.co